

Ventilátor pevně namontujte a poté zapojte napájecí kabel do zásuvky 220-240 V. Nastavte směr proudění vzduchu a zapněte ventilátor.


Technologie magnetického motoru s přímým pohonem je nejnovějším ekologickým řešením a spotřebovává pouze 5W energie.

**UPOZORNĚNÍ:** Ventilátor se může pohybovat v rozmezí od 1,5 do 2,5m: Nedotýkejte se síťové zástrčky mokřýma rukama, abyste předešli nebezpečí úrazu elektrickým proudem. Nevkládejte ruce nebo jiné předměty do lopatek oběžného kola, když je ventilátor v chodu. Zkontrolujte, zda napětí uvedené na výrobku odpovídá napájecímu napětí. Nesprávná instalace může mít za následek riziko požáru, úrazu elektrickým proudem nebo vážného zranění.

Před čištěním, údržbou a přenášením ventilátoru je nutné vytáhnout zástrčku ze zásuvky. Neumísťujte ventilátor na velmi vlhká místa (např. aby nasávala vzduch ze zvlhčovače) a na místa, kde panuje riziko postříkání vodou (např. do koupelny). Pokud ventilátor nepoužíváte, odpojte jej od elektrické sítě. Uchovávejte mimo dosah dětí. Pokud je kabel poškozen, měl by jej vyměnit servisní technik nebo kvalifikovaný technik.



Tento spotřebič by neměl být po skončení své životnosti vyhozen do domácího odpadu, ale musí být odevzdán na centrálním místě pro recyklaci elektrických a elektronických zařízení pro domácnost. Tento symbol na spotřebiči, návodu k obsluze a obalu upozorňuje na tuto důležitou problematiku. Materiály použité v tomto spotřebiči lze recyklovat. Recyklací použitých domácích spotřebičů vážně přispějete k ochraně našeho životního prostředí. Informace o sběrném místě vám poskytne místní úřad.



### W.FAN VFMAGNETIC 5W

Mount the fan securely and then plug the power cable into the 220 - 240V power socket. Adjust the airflow direction and turn on the fan.

The technology of direct drive magnetic engine is the newest ecological solution and consume only 5W of energy.

**BEFOR USE:** Avoid placing fan near curtain and small corners. Do not handle power plugs with wet hands, to avoid risk of electric shock. Avoid to insert hands or other objects in the functioning of the blade. Remove the packaging materials and unravel the cord completely before operation. Please check that the voltage indicated on the product corresponds with your supply voltage.

The fan should not be placed in very humid places (e.g. near the humidifier to avoid humid air intake) and in a place exposed to splashes (e.g. in the bathroom). Unplug from the power supply when the fan is not in use. Keep out of reach of children. If the cord is damaged, should be replaced by a service agent or a qualified technician.



This appliance should not be put into the domestic garbage at the end of its useful life, but must be disposed of at a central point for recycling of electric and electronic domestic appliances. This symbol on appliance, instruction manual and packaging puts your attention to this important issue. The materials used in this appliance can be recycled. By recycling used domestic appliances you contribute an important push to the protection of our environment. Ask your local authorities for information regarding the point of recollection.