

Quantum PAR Meter (MBAR01)

Accurate PAR Measurement for Optimal Plant Growth

User Guide





Thank you for choosing the Maxibright Quantum PAR Meter. This guide will help you get started and ensure optimal use.

Package Includes

- Main Unit (PAR Meter)
- Sensor Unit (¼" screw mount compatible)
- Coiled Cable (1.5m) & Straight Cable (3.5m)
- 2x AAA Batteries
- User Manual

Main Features

Wide measurement range (0 to 3999 µmol/m²/sec) Precision readings with +/-1 µmol/m²/sec repeatability Large LCD display for clear measurements Portable and lightweight (115g) Tripod compatibility for stable measurements Easy-to-use large LCD screen

Setup, Power, and Basic Operations

Initial Setup:

Open the battery compartment. Insert 2x AAA batteries. Close the cover..

Power On/Off:

Press the power button to turn on (located on the side of the main unit) Hold the power button for 3 seconds to turn off.

Basic Operations:

"Hold" Function: Press Enter to freeze the current reading, press again to release. Data Logging: Press LOG to record data, navigate with arrow keys. Tripod compatibility for stable measurements Easy-to-use large LCD screen.

Mode Functions

CALI (Zero Calibration):

Cover the sensor, press MODE until CALI appears, hold Enter for 3 seconds to calibrate.

LOG (Review Data):

Press MODE, navigate to LOG, and use arrows to scroll through recorded data.

RCFS (Factory Reset):

Enter RCFS mode, select "YES," and hold Enter for 3 seconds to reset.

Technical Specifications

Specifications:

Measurement Range: 0-3999 µmol/m²/sec

Display Resolution: 0.1 µmol/m²/sec (up to 999), 1 µmol/m²/sec (1000-3999)

Power: 2x AAA batteries

Weight: 115g (without batteries/cables)
Operating Temperature: 0°C to 50°C
Storage Temperature: -20°C to 60°C

Operating Conditions:

Ensure proper cable connections for optimal function.

Handle with care to maintain calibration accuracy.



Troubleshooting and Safety

Issue: Device won't power on. **Solution:** Replace batteries.

Issue: Display shows "----"

Solution: Check sensor connections and cables.

Issue: No display, only battery icon.

Solution: Replace batteries.

Safety Notice

WARNING: Contains small parts; choking hazard.

Keep RJ11 port free of debris for consistent performance.

Reminder: Store this manual in a safe place for future use.

Thank you for choosing Maxibright